



"You will never be alone on the side of the road"

19A Michelin str. Vanderbijlpark
CELL: 082 929 0057, TEL: 016 986 0129
CELL: 082 921 5121, FAX: 086 772 5040

Website: www.sleepwaparte.co.za
E-mail: sales@sleepwaparte.co.za

Chevron Board:

A chevron board must always be your number 1 choice above reflectors, should the design of the trailer allow for it. Although the chevron board or sticker replaces the reflectors on the back of the trailer, yellow reflective tape is still required.

Reflectors:

1. Seven (7) rectangular red reflectors *or* two (2) red triangular reflectors on the back of the trailer depending on the design of the trailer.
2. One (1) red rectangular reflector on the back of each mudguard, or the furthest side of the trailer.
3. One (1) white rectangular reflector on the front of each mudguard or the furthest side of the trailer.

Lights:

Two number plate lights are required, one on each side, top or bottom depending on the design of the trailer. In addition, the trailer must be fitted with indicator, stop and tail lights. Placement of these lights must be in such a manner that they clearly visible without any obstructions.

Reflective tape:

Yellow reflective tape must cover at least 80% of the trailer in the length and the full width of the trailer at the back.

Data plates:

A data plate must be permanently fixed to the trailer in a clearly visible position, either on the left-hand side of the trailer body or the A-frame.

Micro Dots:

A trailer must be fitted with at least 5000 micro dots. Unfortunately, this can only be done by a qualified person from a registered Micro Dot fitment centre. Also keep in mind that when a trailer is repainted at the bottom, Micro Dots must be fitted again.

Sleepwa Parte would like to thank Burquip International and Vtec Trailers for the information provided.